

Do you need to
recalibrate your
crane scale?

SCAN ME:



DIGITAL CRANE SCALE

KGW | KGW-Y | KGY

Technical manual



Table of content

Table of content	2
Declaration of conformity	3
Explanations to the manual.....	4
Technical data	5
Safety Instructions	6
Warranty	8
Scope of delivery.....	9
Product overview	10
Digital- crane scale KGW KGW-Y KGY	10
Product details.....	12
Eyelet & braket	12
Load hook	12
Heat protection.....	12
LED-Display.....	13
Control panel	15
Infrared remote control	17
Setting the channel of the infrared remote control	21
Charger & Accumulator.....	24
Functions of crane scale	27
Automatic switch-off.....	27
Master - Slave scale function.....	32
Set weight limits	34
Set signal time for weight limits	35
Automatic taring for weight values	36
Accessories	37
Spare part list.....	38
Troubleshooting	39
Error detection.....	41
EHP Servicehotline.....	43

Declaration of conformity

Declaration of conformity

Manufacturer: EHP-Wägetechnik GmbH

Address: Dieselstrasse 8
D-77815 Bühl (Baden)
Germany

hereby declares that the product: **digital crane scale type KGW / KGW-Y / KGY**

Plant number:

Year of manufacture:

complies with the following harmonized standards with all options:

Machinery Directive 2006/42/EC

EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6, EN 61000-4-11 according to the directive 2014/30/EU (electromagnetic compatibility)

EN 61010-031 Part 1/ Safety requirements for electrical equipment for measurement, control and laboratory use

EN 62368-1 Equipment for communication technology - Part 1: Safety requirements

For use as a non-automatic weighing instrument with EC type-approval, the requirements of Directive DIN EN 45501:2015 are met.

The crane scale complies with the requirements of the standard EN 13155:2009-08 "Crane-safety-less load handling attachments".

The following national standards and technical specifications were also applied: DGUV regulation 100 - 500 chapter 2.08.

The product is marked with the CE mark.

A handwritten signature in black ink, appearing to read 'Markus Ebel', written in a cursive style.

Bühl, April 2021

Markus Ebel / Technical Managing Director

This declaration is in accordance with DIN EN ISO/IEC 17050-1.

Explanations to the manual

In this technical manual you will find the necessary information for operating the **digital crane scale KGW | KGW-Y | KGY**.

- ▶ Please read the operating instructions before you put your crane scale into operation. This will protect you and prevent damage to your equipment.
- ▶ Always keep this manual in a place where employees, service personnel etc. can read it. Present this manual to the inspector or the appointed specialist company at each periodic inspection.

Design features of this manual

Various elements of this manual have fixed design features. This allows you to easily distinguish the following elements:

Normal text

- Enumerations
- ▶ Action steps

Table titles and illustrations are printed in bold.

- ① Tips contain additional information.

Design features of illustrations

If reference is made to elements of an illustration in a legend or in the running text, they are given a number (1). The numbers in the running text always refer to the figure shown.



Figure 1 - Explanation of design features

Technical data

Power supply	12V DC maintenance-free accumulator 14.4Ah
Minimum voltage of the accumulator	10.8V DC
Power supply of the IR remote control	3x 1,5V Typ AAA, Micro, LR03, AM4, MN2400
Range of IR remote control	approx. 35m with angle <20°
Operating time	approx. 120 hours
Power supply of the charger	110-230V AC, 50/60Hz
Recharge time of the accumulator	<12 hours
Max. Resolution in CE-M approved version	3.000 parts
Nominal temperature range	-10°C...+40°C
Operating range (without heat protection)	-20°C...+50°C
Protection class	IP 54

Table 1 - Technical data

Safety Instructions

TO BE NOTED

- The unit should only ever be opened by a qualified specialist technician!
- The device must be protected from heat and moisture!



IMPORTANT SAFETY INSTRUCTIONS



Before installation

- The crane scale is suitable for weighing and transporting accordance with EN 13155:2009-08 „Crane safety - section 5.1.1.1 Mechanical load-bearing parts“.
- The crane scale is attached to the hook of a crane in accordance with the regulations.
- The operator is responsible for the safety of the device. Crane scales are load suspension devices according to DIN EN 13155, including accessories such as hooks, shackles and eyes. These parts must be inspected for safety at regular intervals, but after one year at the latest. Visual inspections for damage to tensile stressed parts such as hooks, eyes, connecting links etc. should be carried out continuously.

Especially in 3-shift operation, this inspection cycle must be carried out in accordance with the Industrial Safety Regulation §11.

We recommend a safety inspection every 4 months, and after 12 months at the latest an additional crack detection with the electrical crack detection method or the red-white process must be carried out during this monitoring.

We would be pleased to take over these safety checks for you by sending your device to our head office (EHP Wägetechnik GmbH | Dieselstraße 8 | 77815 Bühl).

- Check that the safety flaps of the hooks are in perfect condition. These prevent hanging loads (ropes, chains, etc.) from unhooking.
- Check that the eyelets, shackles, lower load hooks, bolts and safety pins are in perfect condition. In case of heavy wear ($\geq 10\%$ of the original dimensions) of these parts, please contact the EHP customer service.
- Safety and protective devices must never be removed or modified.
- Make sure that the scale is securely suspended.
- Observe the regulations for prevention of accidents.
- Keep this technical manual in a safe place close to your working area.

When moving loads, avoid at all costs:

- Lifting unevenly.
- Trailing the goods on the floor.
- Sudden lifting or setting down or abrupt stopping.

During use:

- **Staying under lifted loads is strictly prohibited!**
- Always ensure that the scale and load are securely hung up.
- Lifting or transporting persons and live animals with the crane scale is prohibited!
- Loads that are heavier than indicated on the load plate mounted on the side of the crane scale are not allowed to be lifted.
- When lifting the load, move away a few meters and check that the load is correctly balanced by lifting the load a few centimeters from the ground. On the display of the crane scale you can read if the load is exceeded..
- If the display starts flashing or the display shows OL, the maximum load has been exceeded. The load must be lowered again immediately.
- Never allow the load to swing.
- Lift at minimum speed.

For CE-M approved scales (model KGY):

- CE-M approved scales are only approved for use in a weatherproof environment.
- Do not operate the scale at risk of frost (below -10°C) or in a very hot environment (above +40°C). In this temperature range.
- The verification marks and seals on CE-M approved scales must be handled with care. If they are damaged, please notify your regional weight and measures authorities.

In case of malfunctions:

- Repairs may only be carried out by qualified personnel!
- Read the chapter "Troubleshooting" and „Error detection“.
- Contact the EHP customer service.

Warranty

The warranty is void in case of:

- Improper use of the manufacturer's instructions in this technical manual.
- Operating the device in an unintended use.
- Mechanical damage, damage by humidity and liquids.
- Mechanical modification of the crane scale.
- Wear and tear.
- Use of non original EHP batteries, chargers and power supplies.
- Manipulation of the loading device.
- Overloading the crane scale.
- Modification or replacement of the load-bearing parts.

Scope of delivery

- Digital crane scale KGW | KGW-Y | KGY




Figure 2 - Digital crane scale KGW and KGW-Y/KGY

The following accessories are included in the scope of delivery:

- Bracket (KGW) or Mounting eyelet (KGW-Y & KGY)
- Heat protection (only KGW)
- Load hook
- Infrared remote control
- Rechargeable battery 12V/14,4Ah
- Charger 12V/4Ah with charging current limiter

Depending on the product configuration, the accessories may differ from the standard.

Product overview

Digital- crane scale KGW | KGW-Y | KGY




Figure 3 - Front view

The **LED-Display (1)** is located at the front of the crane scale. The control panel with 6 functional keys is covered and protected by a **protection cover (2)**.

The **bracket or eyelet (3)** is located on top of the crane scale and the **load hook (4)** is located at the bottom. The KGW model is also protected from extreme temperatures by a surrounding **heat shield (5)**. Depending on customer configuration, the figure shown above may vary.

At the back of the **digital crane scale KGW | KGW-Y | KGY** the battery box is located, which can be opened by releasing the quick release. Inside the housing is the 12V battery.




Figure 4 - 12V battery/14.4Ah (Article-No. 79849)

This is connected via the two round connectors. The round plugs are designed in such a way that it is not possible to inadvertently swap the + / - poles.




Figure 5 – Round plug for 12V battery connection

Product details

Eyelet & bracket



Figure 6 - Eyelet

The crane scale will be hung up with its eyelet or bracket in the crane hook. It must be ensured that the eyelet can move freely in the hook base of the crane hook, rests properly in the hook and is not tilted.

Load hook



Figure 7 - load hook

The load hook is used to weigh and transport the goods. The load capacity of the load hook matches the load capacity of the crane scale. It is restricted to exchange the hook for any other handling equipment.

The safety catch of the load hook prevents the load from accidentally slipping out. Before lifting the load, make sure that the safety catch is fully closed.

Heat protection



Figure 8 - Heat protection

The surrounding heat protection of the KGW scale model protects the electronics and measuring unit from extreme ambient heat.

LED-Display

The LED display shows the weight of the lifted goods and additional parameter.






Figure 9 - LED-Display

1. 5-digit weight display
2. +/- sign
3. Battery empty
4. PT (PreTara)
5. Net weight value (Tare function activated)
6. 1 / 2 range display
7. Standstill indicator

Display indication	Information
	Display in general The display consists of a 5-digit, 7-segment LED.
	Sign- symbol Every weight is displayed combined with its algebraic sign. Overload display If more than 2e (double number unit) above the nominal weight is added, the display on the scale starts flashing. If more than 9e above the nominal weight is added the crane scale shows "OL" (overload) and switches OFF automatically.









	<p><u>Example:</u> The scale has a weighing range of 10t; calibration value 5 kg x 2e = 10 kg, i.e. the display flashes at a weight exceeding 10010kg and "OL" appears from 10045 kg.</p> <p>Always pay attention that the crane scale is never overloaded due to safety reasons.</p>
	<p>Symbol for battery control</p> <p>If the battery is discharged (at 10.6 volts), the  symbol appears on the display.</p> <p>This indicates that the battery is "empty" and needs to be recharged. If this is not possible immediately because of the work process, you can continue working for approx. 30 minutes. If the battery is discharged (at 10.0 volts), the crane scale switches off automatically to avoid deep discharge and damage to the battery.</p>
	<p>Symbol for preset tare (Pre-Tare)</p> <p>This symbol is shown together with the  - symbol when a tare value is entered manually with the remote control. The weight value displayed is a net weight.</p>
	<p>Symbol for net weight</p> <p>This symbol is shown when a tare value has been entered. The weight value displayed is a net weight.</p>
	<p>Symbols for dual range systems</p> <p>For dual range scales, this symbol indicates the weighing range in which the crane scale operates. The weighing ranges are printed on the nameplate of the crane scale.</p>
	<p>Standstill display / Peak value display</p> <p>The illuminated symbol means that the load on the scale is hanging steady and a valid weight value is shown.</p> <p>If the  symbol flashes, then the peak value display or the casting speed display has been activated with key 9 on the remote control.</p>




Table 2 - Display indication

Control panel

The crane scale can be operated via the integrated control panel below the LED display.



Figure 10 - Control panel

Button	Function
	<p>Power-On</p> <ul style="list-style-type: none"> • Switch on the crane scale • Activates the automatic segment control • Crane scale automatically is set to „0“ <p>Always switch on the crane scale 5 minutes before the first weighing operation.</p> <p>If the preload (e.g. slings) is greater than 20%-30% of the nominal load, only the + sign is shown. The scale then switches itself off.</p> <p>The normal operating mode is only reached again by reducing the preload and switching on again.</p>
	<p>Power-Off</p> <ul style="list-style-type: none"> • Switch off the crane scale <p>Switch off crane scale eliminates temporary errors (reset function).</p>
	<p>Test-Routine</p> <p>By pressing this key, a check of each individual display segment (segment check) is performed and further information of the scale will be shown.</p> <p><u>For approx. 5 seconds, the display flashes consecutively:</u></p> <p>8 8 8 8 8 (Segment control)</p>




	<p>L A H (Software version)</p> <p>1 2 . 2 1 (Version number, Release)</p> <p>0 1 (Scale number)</p> <p>C 0 1 (Channel frequency)</p> <p>H 0 1 (Canal of IR remote control)</p> <p>I n I t (Self test of crane scale)</p>
	<p>TARE-Button</p> <ul style="list-style-type: none"> • TARE (subtractive) is activated • Scale stores the current weight value in the tare memory • Display shows "0" • Net- weight symbol is shown • Pressing the TARE button again resets the tare function, clears the tare memory and the display shows the gross weight again, the Net- weight symbol disappears
	<p>Zero-Button</p> <ul style="list-style-type: none"> • Sets weight to "0" (semi-automatic zero setting device). • Zeroing range: -1 to +3% of nominal load for LDN model; • max. zeroing range: -99 to +99% of nominal load (LD model) <p>„Zero" is not possible outside this zeroing ranges or in tare mode.</p>
	<p>Button for advanced functions</p> <p>By default, this key is not assigned any function. On customer request, this key can be equipped with special functions.</p>

Table 3 - Control Panel

Infrared remote control

The infrared remote control has a robust housing and is equipped with large control buttons that can be easily operated even when wearing gloves.

All functions of the crane scale can be controlled via remote control, such as OFF, TARE or zeroing. Furthermore, the remote control offers further operating possibilities, which are used in connection with EHP weighing data receiving units, such as the print function.

① Up to a distance of 30m the crane scale can be operated with the remote control. If the working range should shorten (less than 20m), this is an indication that the batteries need to be changed (3 pieces 1.5V Type AAA, Micro LR03, AM4, MN2400).















Figure 11 - Infrared remote control

NOTE

Some functions like Print, Add or Total can only be used in combination with EHP weighing data receiver (see **Accessories** on page 37).

1		TARE-Button This button has the same function as on the crane scale control panel.
2		PRINT-Button Press this key to transfer the weighing data to optionally available EHP receiving devices (see Accessories on page 37). For example, an individual receipt can be printed out on TELEDATA USB weighing data receiver.
3		ZERO-Button This button has the same function as on the crane scale control panel.
4		ADDITION-Button Pressing this key activates the addition function. This function helps to store individual weights within a batch or to add them. This function can only be used with additional weighing data receiving units, e.g. the TELEDATA USB.
5		Dual range shift-Button Press this key to switch the increment range of your scale (this function is not included in standard crane scales. For example, from 1 kg increments to 2 kg increments). Note: The scale automatically switches to the second range as soon as a corresponding load value is reached. After the load has been removed (0 kg display on the scale), you can switch back to the first measuring range. It may be necessary to press the zeroing button beforehand to record an exact 0 kg value.
6		Print Total-Button Herewith the total weight (plus additional data) is transmitted by radio to weighing data receiving units, e.g. the TELEDATA USB. At the integrated printer a sum voucher (addition of the single registrations transmitted by add function) is printed out.

7		<p>Test-Routine-Button</p> <p>This button has the same function as on the crane scale panel.</p>
8		<p>OFF-Button</p> <p>Press this button to switch off the scale via remote control. The display flashes 10x off during the switch-off phase. During this time you can interrupt the switch-off process by pressing any key.</p>
9		<p>Special function Button</p> <p>This button can be assigned with any special functions like showing the peak value or displaying the casting speed.</p> <p>Special functions are not included in the standard scope of delivery. Contact your EHP contact person for further information.</p>
10		<p>Pre-Tare-Button</p> <p>Press this button to activate the pre-tare function. The display shows now the last pre-tara value. Use the keys 1 to 0 to enter the tare value and confirm with the ENTER key. The tare values must lie within a calibration value. Higher or lower values are rounded up or down.</p>
11		<p>Shift-Button</p> <p>Pressing this button activates the numeric buttons on the IR remote control. Additionally the LED above the shift key is flashing. Now any numbers from 0...9 can be entered as a code (maximum 5 digits). Press the ENTER key to confirm the entry, the Shift LED goes out again.</p> <p>This code is now transmitted to the weighing data receiver.</p>



12		Enter-Button Press this key to confirm the numerically entered values.
13		Send-LED Flashing of this LED indicates that the IR remote control is transmitting data.

Table 4 - Buttons of IR remote control

Setting the channel of the infrared remote control

Manual channel setting

To establish communication between the scale and the remote control, the transmission channel may have to be adjusted.


1. By pressing the „TEST“-Button the crane scale display shows the current setting parameter in following sequences:



88888	=	Segment test
LAH	=	Release
12.21	=	Version
xx	=	Scale number (01-16)
Cxx	=	Canal number (01-28)
Hxx	=	Remote control number (01-12)

The remote control number Hxx (for example: H01 for channel 01) indicates on which remote control channel the crane scale's infrared sensor receives data.

2. Set the remote control to the same channel as the infrared sensor of the crane scale. You can access the setup menu by pressing the following key combination quickly one after the other.




The red LED above the SHIFT key will then light up for 5 seconds, which visualises that you are in the setup menu. During this time the remote control number can be changed.

To change the remote control number, type in the key combination 2xx. Where xx corresponds to the desired channel number. Possible values are 201 (1st channel) to 212 (12th channel).


Example:

After pressing the TEST button on the crane scale the setting parameters are shown with the remote control number H01. This indicates that the crane scale is sending on Channel 1.

Therefore the IR remote control must be set to the transmission channel by pressing the key combination:



and then followed by the key combination 2 0 1.



The remote control now transmits on the same channel as the crane scale.

NOTE


To set the channel of the infrared remote control to a defined number please ensure that the crane scale channel number is also set to this number.

For more information on changing the crane scale parameters, refer to section „Functions of crane scale“.

Automatic channel search

The channel number search can be performed automatically.

Align the infrared remote control with the crane scale display. Press the following key combination quickly, one after the other:



The canal search is indicated by blinking of the transmitter LED. As soon as the scale reacts to the signal of the remote control press ENTER again.

The canal number will be stored automatically indicated by the flashing LED.

Charger & Accumulator

The supplied **12 volt charger (1)** can be connected directly to the charging socket of the crane scale. The accumulator can also be charged directly using the **adapter (2)**.

The **status LED (3)** indicates the charging status of the accumulator.



Figure 12 - Charger & adapter

NOTE

The charger is only suitable for charging maintenance-free original EHP accumulators. The charger cannot be opened.

If the device is damaged due to improper opening, the warranty is voided. Before putting the device into operation, make sure that sufficient ventilation is provided.

The charger may only be operated in closed rooms and should not be exposed to moisture. Any modification to the charger will invalidate the device approvals.

Connecting the charger



	<p>At the front of the crane scale is the charging socket, as well as the fuse holder (fuse 1A, 5 x 20mm.)</p>
	<p>The plug of the charger is inserted into the charging socket. Before disconnecting the charger cable, the plug lock must be pressed.</p>

Table 5 -Connecting the charger

When the charger is connected, the status LED on the charger lights up. The different colours have the following meaning:




Status - LED	Information
	<p><u>LED lights up red:</u></p> <p>Accumulator is charged with a current of 4A.</p>
	<p><u>LED lights up orange:</u></p> <p>Accumulator status is analyzed.</p>
	<p><u>LED lights up green:</u></p> <p>Accumulator is charged, the charger has switched to trickle charge (max. 50 mA charging current). Overcharging is not possible.</p>

Table 6- Status LED of charger

Instructions for use of original EHP accumulators

- With delivery the accumulator is already charged for 8 hours and is immediately ready for use.
- The accumulator should never be stored uncharged.
- A completely discharged battery requires at least 12 hours of charging.
- If the charging time is less than 12 hours, a longer charging period of approx. 24 hours is recommended for the next time.
- To avoid deep discharging, charge the accumulator immediately after the BAT symbol appears on the crane scale display.
- The accumulator should be charged at room temperature. Temperatures below 10°C and above 30°C should be avoided during charging.
- Deep discharging must be avoided.

NOTE






If the accumulator is not used for a long time period, it should either be fully charged again or stored with the charger connected (trickle charge). Cool and light protected storage rooms are recommended.

After longer periods of non-use of more than 3 months or after deep discharge, the battery should be charged for at least 24 hours.

Functions of crane scale

Automatic switch-off

The crane scale is equipped with an automatic switch-off function, which is deactivated by default. The automatic switch-off is activated using the buttons on the control panel, as described in **Table 7**.

1		With the crane scale switched on, press the Power On and TEST buttons simultaneously to open the SETUP menu. EEEEEE appears on the display.
2		Then press the TEST key repeatedly until P07 appears in the display.
3		Use the TARE key to activate the parameter to call up the position to be changed. Enter a value between 01-60 with the TEST key. This value indicates after how many minutes the crane scale should switch off.
4		Use the ZERO key to temporarily save the parameter value.
5		Press the TEST key repeatedly until P99 appears on the display.





6	 	<p>Press the TARE key, then press the ZERO key.</p> <p>S t o (Store) flashes several times in the display. This permanently stores the parameter change.</p>
7	 	<p>To exit the SETUP menu, press the Power-On and Power-Off buttons simultaneously or interrupt the power supply by disconnecting the round connectors at the accumulator.</p>

Table 7 - Activate automatic switch off function

Change radio frequency, scale number and infrared channel of the scale

Some parameters can be adjusted by the enduser.

These adjustments can be useful, for example, if several EHP crane scales are operated at one location and the radio link might be disturbed by other machines.


















88888	=	Segment test
LAH	=	Release-Firmware
12.21	=	Version-Firmware
xx	=	Scale number (01-16, as identification number)
Cxx	=	Channel number (01 - 28, radio frequency channel)
Hxx	=	IR remote control number (01-12)

To change the scale number, channel number or remote control number, proceed as follows:

NOTE

If a parameter should not be changed, it can be skipped by pressing the TEST button.

1	 	With the crane scale switched on, press the Power On and TEST buttons simultaneously to open the SETUP menu. EEEE appears on the display.
2		Press the TEST key repeatedly until P13 appears on the display. Parameter P13 is used to set the radio frequency channel (Cxx).
3	 	Press the TARE key to activate the parameter. Then use the TEST key to select a desired value between 01 - 28 (corresponds to channel 01 - 28).

4		<p>Confirm and close the parameter by pressing the ZERO key.</p> <p>The display alternately shows P13 and xx, where xx corresponds to the newly set channel number.</p>
5		<p>Press the TEST key repeatedly until P14 appears in the display.</p> <p>Parameter P14 is used to set the scale number.</p>
6	 	<p>Press the TARE key to activate the parameter.</p> <p>Then use the TEST key to select a desired value between 01 - 99 (corresponds to channel 01 - 99).</p>
7		<p>Confirm and close the parameter by pressing the ZERO key.</p> <p>The display shows P14 and xx alternately, where xx corresponds to the new scale number set.</p>
8		<p>Press the TEST key repeatedly until P18 appears in the display.</p> <p>Parameter P18 is used to set the remote control number.</p>
9	 	<p>Press the TARE key to activate the parameter.</p> <p>Then use the TEST key to select a desired value between 01 - 12 (corresponds to remote control number 01 - 12).</p>
10		<p>Confirm and close the parameter by pressing the ZERO key.</p> <p>The display alternately shows P18 and xx, where xx is the new remote control number.</p>
11		<p>Press the TEST key repeatedly until P99 appears in the display.</p> <p>Parameter P99 is used to store the changed values.</p>





12	 	<p>Press the TARE key to activate the parameter.</p> <p>Confirm and close the parameter by pressing the ZERO key.</p> <p>Sto (Store) flashes several times on the display. This indicates that the parameter change has been successfully stored.</p>
13	 	<p>To exit the SETUP menu, press the Power-On and Power-Off buttons simultaneously or interrupt the power supply by disconnecting the round connectors on the battery.</p>

Table 8 - Change radio frequency, scale number and infrared channel of the scale

Master - Slave scale function

This function is only available with special equipment (two or more EHP crane scales incl. radio equipment needed). Master -Slave scale function can be retrofitted at existing scales. Please contact your EHP contact person.

Up to four EHP crane scales can be used in a compound system (Master - Slave) to weigh long materials or large assemblies.





Figure 13 - Master – Slave scale function with two KGW crane scales

Calibrated master – slave system

The master scale displays the total weight of all scales used within the system.

The slave scales show no weight, its readiness for operation is signalled by the display "__x__", where x corresponds to the respective slave scale number (1 - 3 possible).

If all scales used within the system have registered a valid weight, the stability indicator () is shown in the display of the master scale.

Zeroing or taring always affects the entire system, i.e. if the "O" or "TARE" key on the master scale is pressed, the weight measured by each individual scale is zeroed or stored in the TARE memory.

The master scale can also be operated independently, however, please note that due to the missing feedback signals of the slave scales, no stability indication is displayed and therefore printing or processing of the weighing data by radio is not possible.

NOTE

The activation / deactivation of the master – slave function requires scale setup adjustments which can only be carried out in agreement with the manufacturer.

Please contact directly EHP Wägetechnik GmbH.

CE-M approved master – slave system

The following characteristics apply only for CE-M approved master – slave systems:

- Each scale displays its own weight
- The scales are operated separately with the infrared remote control
- With the optional DRC 433 wireless remote control, only the master scale can be operated.
- The sum of all scales is shown in the display of the respective weighing data receiver.

- Tare setting:

Variant 1: The tare weight is set by using the tare button on the device or by remote control on the respective crane scale.

Variant 2: The tare weight is set on the weighing data receiver for the master and slave scales. The weighing data receiver is tared by pressing the "M/S Tare (U)" key for a longer period.

Set weight limits

This function can only be used with optional equipment.

With this function an acoustic signal or a warning message as output can be given out when certain weights are reached. You can enter up to four different weight values.










IR-remote control	Display	Comment
	AL	Open the function menu by pressing ENTER.
	L1 L2 L3 L4	Selection of weight limit. Button 1 to select weight limit 1 (L1), Button 2 to select weight limit 2 (L2) etc..
	00000	Use ENTER to select weight limit. Enter the required weight by using the remote control.
	00500	Example for weight limit of 500kg (If no entry is made, the display returns to the "AL" menu after 5 seconds).
	00500	Save weight limit (display flashes).
	AL	Return to function menu. Input of further weight limits possible by pressing buttons  ,  or  . Leave function menu by pressing  again.

Table 9 - Set weight limits

Set signal time for weight limits

As soon as a weight limit value (L1-L4) is reached, an acoustic signal sounds or a warning message is given out. The duration of the signal can be selected as a continuous signal or limited in time between 1-9 seconds.

This function can only be used with optional equipment.






IR-remote control	Display	Comment
	AL	Open the function menu by pressing ENTER.
	Beispiel: Hrn 4	Press button 5 to change signal duration. The set signal duration (in seconds) is displayed. A default value of 4 seconds is preset (Hrn 4).
Beispiel: 	Beispiel: Hrn 2 (Signaldauer 2 Sek.)	To change the signal duration, press the respective button number on your remote control. The button number corresponds to the signal duration in seconds. Button number 0 (Einstellwert Hrn 0) activates the continuous signal. The continuous signal stops when the weight is below the respective weight limit.
	Hrn 2	Save (display flashes).
	AL	Return to function menu. Set further functions or leave menu by pressing  again.

Table 10 - Set signal time for weight limits

Automatic taring for weight values

With this function automatic taring is performed as soon as one of the defined weight values (L1-L4) is reached.

This function can only be used with optional equipment.






IR-remote control	Display	Comment
	AL	Open the function menu by pressing ENTER.
	tAr 0	Autotaring is deactivated as default value.
	tAr 1	Autotaring enabled by pressing button 1.
	tAr 1	Save (display flashes).
	AL	Return to function menu. Set further functions or leave menu by pressing  again.

Table 11 - Automatic taring for weight values

Accessories

EHP crane scales can be upgraded with a radio transmitter unit to send weighing data to EHP receiving units. This allows weighing data to be processed quickly and easily. A selection of additional accessories is shown below.

For more information, please contact your weighing partner or directly EHP-Wägetechnik GmbH (www.ehp.de).



Figure 14 - Overview accessories

Spare part list

Order number	Description
50182	Heat resistant glazing 303 x 95 x 9 mm
73326	Heat resistant glazing (for KGW 15-100 till 2011)
10700	Infrared remote control 12 Button
79849	Accumulator 12 V/ 14.4 Ah
79860	Accumulator 12 V/ 21.6 Ah (for KGW/KGW-Y/KGY 15-100 till 12/2015)
58366	Power cable KGW / KGY / LK with round connectors
78206	Complete digital display
55385	Fuse holder
55198	Charging socket (till 2010)
10087	Charging socket (from 2011)
53944	Keyboard platine
79827	Foil for keyboard platine
10701	Charger 12 V / 4 Amp. charging socket V1 (till 2009)
10702	Charger 12 V / 4 Amp. charging socket V1 (from 2010)
59114	Heat-/ram protection shield KGW 1-10
59136	Heat-/ram protection shield KGW 15-30
78276	Heat-/ram protection shield KGW-Y/KGY 15-40
10213	BNC antenna 433 MHz complete with heat protection cap
53449	Antenna with connector

Table 12 - Spare part list

Troubleshooting

Problem	Cause	Solution
Display is dark	No power	Check if crane scale is switched on. Check if accumulator is charged. Check condition of fuse.
After switching on, the display briefly shows the "+" sign and then switches off automatically	The crane scale is beyond the zero setting range	Switch off scale, unload and switch scale on again.
Display flashes	Crane scale is overloaded	Reduce the weight below the maximum capacity of the scale (see load plate on the right side of the scale).
Display shows OL	Severe overload of the crane scale	Immediately reduce the weight to a value below the maximum capacity of the scale (see load plate on the right side of the scale).
Crane scale cannot be switched off	Negative weight value recorded outside the zero setting range (3% of the load capacity on verified scales)	Replace fuse and switch scale on again.
Scale cannot be zeroed	Balance is outside the zero setting range (only for LDN – CE-M approved)	Reduce the load to reach the zero setting range of the CE-M approved scale.
	Balance is used with TARE function (Net – LED is on)	Press the TARE key again to exit the TARE mode of the scale.
	Load at crane scale hook is swinging and an exact weight value cannot be recorded	Pick up the load again carefully without swinging, wait for standstill indication.

Problem	Cause	Solution
Displayed weight changes rapidly	Load is swinging	Pick up load more carefully.
	Strong temperature fluctuations	Switch crane scale off and let it adjust to ambient temperature for several hours.
Battery can no longer be used	Battery charger defect / not connected	Check power supply.
	Charger LED lights green	The battery has been deeply discharged, leave the battery on the charger for 48 hours.
	Battery gets hot during charging	Battery is worn out.

Table 13 - Troubleshooting list

Error detection

Automatic error detection routines cyclically check the functions of the crane scale and ensure a proper operation.

If an error is detected, it is automatically indicated on the display in the form of an error code. The balance switches off automatically after approx. 5 seconds.

Error code	Cause	Solution
Err 02	The input voltage of the measuring amplifier is too low.	Switch scale off and on again to see if Error is detected again. Contact your EHP Service partner for further information.
Err 03	The input voltage of the measuring amplifier is too high.	Switch the scale off and on again. Contact the customer service.
Err 04	AD-Converter error	Switch the scale off and on again. Contact the customer service.
Err 05	Error radio modem	An incorrect radio channel was set or the modem is defect.

Table 14 - Error codes

[illegible]

EHP Servicehotline

Do you need our support?

No problem - just call us free of charge!



Hotline: +49 7223 9366-0

**Reach our technical experts from Monday to
Thursday between 8 am & 4 pm (CET) and
Friday between 8 am & 12 am (CET).**



EHP Wägetechnik GmbH

Dieselstraße 8

77815 Bühl

Germany