



NET-SCALE V13

Technical Manual



Table of content

Table of content	2
Explanation to the manual	3
Technical data	4
Declaration of conformity	5
Safety instructions	6
Scope of delivery	7
INI-File	8
UDP- / TCP-Protocol	9
General.....	9
Configuration.....	9
Data sets for weighing operation	11
Set Zero "01"	11
Set Tare "02"	11
Delete Tare "03"	11
Set Fixtare "04".....	11
Select scale "05"	11
Register weight at stability "10"	11
Manual registration "12"	12
Data sets for service	12
Firmware-version "F0"	12
Set date/time "F1".....	12
Query for measured value once "F9"	14
Data security	16
Data protocol 28 byte EHP scales	17
Channel frequency	19
Change frequency and scale number	20
Test Software NetScale.exe Demotool	23
Scale 99 Software	25
Functions: Important notes	28
EHP Servicehotline	29
EHP WÄGETECHNIK GmbH	30

Explanation to the manual

In this technical manual you will find the necessary information for operating the **Net-Scale V13**.

► Always keep this manual in a place where employees, service personnel etc. can read it.

Design features of this manual

Various elements of this manual have fixed design features. This allows you to easily distinguish the following elements:

Normal text

• Enumerations

► Action steps

Table titles and **illustrations** are printed in bold.

❗ Tips contain additional information.

Design features of illustrations

If a reference is made to elements of an illustration in a legend or in the running text, they are given a number (1). The numbers in the running text always refer to the figure shown.



Figure 1 – Explanation of design features

Technical data

Input voltage	+8-16V DC / 1,0W
Frequency range	433 MHz band
Network connection	10/100 base-T with TCP/IP Stack
Protocol format	UDP or TCP selectable
Housing	Aluminium housing
Dimensions	13 x 8 x 4 cm
Weight	0,4 kg
Nominal temperature range	-10°C...+40°C
Protection class	IP 54

Table 1- Technical data

Declaration of conformity

Declaration of conformity

Manufacturer: EHP- Wägetechnik GmbH

Address: Dieselstrasse 8

D-77815 Bühl (Baden)

Hereby declares that the product: **Data receiver Type Net-Scale V13**

with the options:

complies with the following harmonized standards.

EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6,
EN 61000-4-11 according to directive 2014/30/EU (elektromagnetic compatibiltiy)

EN 60950-1:2006 in accordance with Directive 2014/35/EU (Low Voltage Directive)

The radio equipment complies with Directive 2014/53/EU

This product is marked with the CE mark.

Bühl, March 2022


Markus Ebel / Technical Manager

This declaration is in accordance with DIN EN ISO/IEC 17050-1.

Safety instructions

TO NOTE

- Device should only be opened by a qualified technician!
- Device must be protected from heat and moisture!



IMPORTANT SAFETY INSTRUCTIONS



► To avoid exposing yourself to the risk of an electric shock, do not open the housing for general use. There is a certain risk to get in contact with non-insulated parts inside the housing that carry a high voltage.

Opening the housing is only permitted to perform the initial configuration if the power connection has been disconnected beforehand. Repairs should only be performed by qualified customer service.

► This device is not waterproof. To avoid the risk of electric shock protect the device from dripping water, splashing water, rain and moisture.

► Do not place any fire source on this device (e.g. burning candles).

► Avoid installing the device in an insufficiently ventilated, very humid or hot place.



To completely disconnect the device, all plugs must be pulled out. To avoid any damage disconnect the Net-scale when not in use for a longer period of time.



► When disposing, do not mix the product with ordinary household waste. There is a separate collection system for used electronics which ensures that the materials are properly recycled according to legislation rules.

Scope of delivery

- Net-Scale V13




Figure 2 - Overview Net-Scale V13

1. BNC angle antenna
2. Network connection (LED status: green = processor in use; yellow = network connected)
3. Power supply connection socket
4. Slot for SD-card

The following accessories are included in the scope of delivery:

- 12 V power supply unit
- BNC angle antenna
- SD card
- Installation CD

INI-File

The Net-Scale must be configured to operate with the scale. This is done via entries in the "NSC.INI" file on the SD card. A operation without an INI-file is not possible!

Entry	Explanation
FREQ=x	Frequency channel for communication with the scale (1-28)
DIMZ=kg	Dimension sign (double digits)
NKOM=0	Amount of decimals; If this entry is deleted, the amount of decimals set at the scale is used
IPAD=xxx.xxx.xxx.xxx	IP address FIX (without DHCP)
MASK=255.255.255.xxx	Subnet Mask (without DHCP)
GATE=xxx.xxx.xxx.xxx	Gateway
PORT	Port for the assignment of the service. Selectable from 1 to 65535 (Default port is 187, ensure that it does not collide with any other service)
WDHL=1...5	Amount of communication attempts between Net-Scale and scale
ACT= 1.....16 (from firmware 2.12)	<p>Activate communication to scales permanently By entering the scale number in the INI file, a permanent connection is established, independent of the configuration of the network interface. A separate entry must be created for each scale.</p> <p>This facilitates the integration of the Netscale in order to be able to use commands such as "Register weight - 10" (see page 11) without programming effort or to establish communication with an EHP large display if no permanent IT connection of the network interface is intended.</p> <p>Note: When using a large display, the Netscale is limited to use with one scale.</p>

Table 2 - INI-file entries

NOTE

The SD-card is mounted as an ftp drive as soon as the Net-Scale is power connected. If the SD card is removed during operation, it must be mounted again. Therefore disconnect the Net-Scale from power supply and reconnect it after a few seconds.

INI File must be named in capital letters (Dateiname: NSC.INI)!

UDP- / TCP-Protocol

General

- The electronic is equipped with a 100base T Ethernet port with TCP/IP stack.
- This description is limited to the protocol variant UDP and the data sets of the module required for weighing operation.
- Data traffic is handled via a selectable UDP- or TCP port (default=187). A basic understanding of the IP (UDP or TCP) protocol is assumed.
- Several commands can be lined up in a data record (separated by semicolon „;“). Only the last command may generate a feedback. For example: select scale #9 in a data record and make a registration „0509;10“.

Configuration

To configure the network interface the 6-pole DIP switch (1) inside the module is used. Therefore the Net-Scale housing must be opened on the side of the Ethernet connection.



Figure 3 - Position DIP-Switch

NSC.	S 1/1	S 1/2	S 1/3	S 1/4
1	1	0	0	0
2	0	1	0	0
3	1	1	0	0
4	0	0	1	0
5	1	0	1	0
6	0	1	1	0
7	1	1	1	0

Table 3 - NSC-setting

- The first 3 DIP switches (1-3) give a unique network name to the module. The name always starts with „NSC“ and a digit „0“ to „7“ - depending on switch position.

- Attention: the network name can be replaced by a specific name with the Netscale demo tool.

- The fourth DIP switch is used to switch the protocol type between UDP and TCP. 0= UDP protocol; 1 = TCP protocol. The connectionless, packet-oriented UDP protocol is activated ex works. Advantage of UDP-protocol is that several hosts have simultaneous access to the Netscale. With activated DIP switch 4 = 1, the TCP protocol is activated, which guarantees connection security. An automatic timeout of 120 seconds is stored for the TCP protocol. When the TCP protocol is activated, connection security is guaranteed. An automatic timeout of 120 seconds is stored for the TCP protocol. When TCP protocol is activated , a rudimentary TELNET protocol is simultaneously available on port 23.

Notice

With activated TCP protocol the „test Software NetScale.exe Demotool“ does not work!

- The fifth DIP switch activates the DHCP mode (=1). If activated it gets the IP address from DHCP host.

- The sixth DIP switch sets the IP-address to “192.168.0.1” (used for service purpose).

- Attention: IP address can be replaced temporary by a special address with the help of the Net-Scale Demo Tool. DHCP options must be disabled via DIP switch 5.

Data sets for weighing operation

Set Zero "01"

Host to Scale	"01"
Scale to Host	No feedback

Set Tare "02"

Host to Scale	"02"
Scale to Host	No feedback

Delete Tare "03"

Host to Scale	"03"
Scale to Host	No feedback

Set Fixtare "04"

Host to Scale	"04 vnnnnn" vnnnnn = Tare with sign
Scale to Host	No feedback

Select scale "05"

Host to Scale	"05 ww" ww = scale-No. (01-16)
Scale to Host	No feedback

Register weight at stability "10"

This command is only available with active communication with the scale (see "F8" page 13). Alternatively, a scale can also be activated automatically by means of INI file parameter ACT (see "ACT" page 8).

Host to scale: "10"

Scale to host: "w rrrrr ddmjjjj hhmss ssnnnn dd sstttt dd iii.iii.iii c"

Entry	Explanation
w	Scale number (A-P, where A=1 ... P=16)
rrrrr	Register number (5-digits)
ddmmjjjj	Date
hhmmss	Time
ss	Space
nnnnn	Net weight (5-digits)
ss	Space
ttttt	Tare weight (5-digits)
dd	Dimension
iii.iii.iii.iii	IP-address
c	Block check character
„E1“	Error: Alibi memory full
„E2“	Error: no standstil, overload, negative weight etc.
„E4“	Error: Communication with scale is interrupted or scale is not connected, the checksum on the data set was incorrect.

Manual registration "12"

Host to scale	"12"
Scale to host	See above – record „10“ „E0“ – Error: no manual registration available

Data sets for service

Firmware-version "FO"

Host to scale	"FO"
Scale to host	" – FONSC-5.G2.11 – " (firmware version)

Set date/time "F1"

Host to scale	"F1 jj mm tt hh nn ss"
Scale to host	No feedback

Entry	Explanation
jj	Year
mm	Month
tt	Day
hh	Hour
nn	Minute
ss	Second

Select frequency channel "F3"

Host to scale	"F3 ff" ff = frequency channel (01..28 see also frequency table)
Scale to host	No feedback

Notice:

It is recommended to change the channel via INI file. See also chapter INI file. The channel changeover may only be carried out once for initialization of the Net Scale module. If the channel change is permanently combined with other commands, the function of the unit is significantly restricted!

Query for measured value "F8"

Host to scale	"F8 [T]"
Scale to host	"F8 x f ssnnnn dd [sstttt ee] c"

Entry	Explanation
x	Status byte 0 ⁰ = Stability indication 0 ³ = tared 0 ⁴ = Weighing range 0 ⁶ = always active
f	Errorcode 1 ⁰ = Overload 1 ¹ = Test 1 ⁴ = battery empty 1 ⁶ = always active
ss	Space
nnnnn	Measured value (5-digits)

tttt	Tare value (5-digits)
dd	Dimension
ee	Dimension (or „PT“ at Fix tare)
c	Block check character
E4	Error: Communication with scale is interrupted or scale is not connected, the checksum on the data set was incorrect.

Query for measured value once "F9"

This setting is relevant for systems where multiple Netscale units operate on the same radio frequency.

Host to scale	"F9 [T]"
Scale to host	"F9 x f ssnnnn dd [sstttt ee] c"

Entry	Explanation
x	Status byte 0 ⁰ = Stability indication 0 ³ = tared 0 ⁴ = Weighing range 0 ⁶ = always active
f	Errorcode 1 ⁰ = Overload 1 ¹ = Test 1 ⁴ = battery empty 1 ⁶ = always active
ss	Space
nnnnn	Measured value (5-digits)
tttt	Tare value (5-digits)
dd	Dimension
ee	Dimension (or „PT“ at Fix tare)
c	Block check character
E4	Error: Communication with scale is interrupted or scale is not connected, the checksum on the data set was incorrect

Notice:

If the character „T“ is added to the command codes, the response data set will also contain the current tare weight.

Examples status byte

	0 ⁷	0 ⁶	0 ⁵	0 ⁴	0 ³	0 ²	0 ¹	0 ⁰	ASCII
Binary	0	1	0	0	0	0	0	0	@
Stability indication = no Tare = no Weighing range = Range 1 (corresponds to 0)									

	1 ⁷	1 ⁶	1 ⁵	1 ⁴	1 ³	1 ²	1 ¹	1 ⁰	ASCII
Binary	0	1	0	0	0	0	0	1	A
Stability indication = no Tare = no Weighing range = Range 1 (corresponds to 0)									

Data security

Data records with OIML-approved information are secured with an blockcheck character.

This block check character is formed by exclusive OR nexus of all characters of the data set and then OR with 0x40.

When receiving such a secured data set, the integrity of the data must be ensured by checking the block check character.

Data protocol 28 byte EHP scales

The extended data protocol (28 byte) has the following data format which is the original protocol of the scale. This is only required if other weighing data receivers are operated parallel to the Net-Scale.

Byte #	ASCII	Meaning
1.	S	Start byte
2.	0	No comma (e.g. 19520)
	1	One decimal (e.g. 1952.0)
	2	Two decimals (e.g. 195.20)
	3	Three decimals (e.g. 19.520)
	4	Four decimals (e.g.. 1.9520)
3.	Blank (20H)	No sign
	+	Plus
	-	Minus
4.	Digit 5	5th digit of weight indication (e.g. <u>1</u> 0320 kg)
5.	Digit 4	4th digit of weight indication (e.g. 10 <u>3</u> 20 kg)
6.	Digit 3	3rd digit of weight indication (e.g. 103 <u>2</u> 0 kg)
7.	Digit 2	5nd digit of weight indication (e.g. 1032 <u>0</u> kg)
8.	Digit 1	1st digit of weight indication (e.g. 10320 <u>0</u> kg)
9.	B	Scale Tare OFF (Gross-weight)
	N	Scale Tare ON (Net-weight)
	P	Scale Pre Tare Active (Net-weight)
10.	E	Single-range-scale
	1	In weighing range I
	2	In weighing range II
11.	0	No stability indication
	1	Stability indication
12.	0	free
13.	V	Accumulator of scale is charged completely
	H	Accumulator of scale – forewarning
	L	Accumulator of scale – Discharged/Empty
14.	(1 – 99)	Digit 1 of Scale number
15.	(1 – 99)	Digit 2 of Scale number
16.	Blank (20H)	free (space HEX20)

Byte #	ASCII	Meaning
17.	N J G	No overload Overload Preload too high
18.	+	Sign, always plus
19.	Digit 5	5th digit of Tare
20.	Digit 4	4th digit of Tare
21.	Digit 3	3rd digit of Tare
22.	Digit 2	2nd digit of Tare
23.	Digit 1	1st digit of Tare
24.	x	Checksum
25.	x	Checksum
28.	03 H	End of block - character (03 Hex)

Table 4 – Data protocol

Channel frequency

It is necessary to use a free frequency for a correct connection between scale and Net-Scale. Other radio transmitting devices like the crane control may massively impair the data exchange

Please note: The radio frequency of the scale is shown on the name plate of the scale. This can be changed in scale setup menu (see chapter „Change frequency and scale number“).

Channel No..	Frequency in MHz	Channel No..	Frequency in MHz
00	-		
01	433,075	15	434,000
02	433,125	16	434,075
03	433,175	17	434,150
04	433,225	18	434,225
05	433,275	19	434,300
06	433,325	20	434,375
07	433,400	21	434,425
08	433,475	22	434,475
09	433,550	23	434,525
10	433,625	24	434,575
11	433,700	25	434,625
12	433,775	26	434,675
13	433,850	27	434,725
14	433,925	28	434,775

Table 5 - Frequency table IR500 radio (500m) 433MHz band

Change frequency and scale number

The Net-Scale protocol requires that Scale number and frequency are matching. Receiving scale data is only possible if both values are identical with call-up commands of Net-Scale.














► By pressing the „TEST“-Button, the crane scale display shows the current setting parameter in following sequences Parameter No.4 and No.5 are relevant.

Nr.	Anzeige	Erläuterung
1	88888	LED segment test
2	LAH	Release
3	12.21	Version
4	xx	Scale number (01-16)
5	Cxx	Channel number (01-28)
6	Hxx	Remote control number (01-12)

Table 6 – Parameter settings

To change the scale and channel number proceed as followed:

Key combination	Function
 	Press ON and TEST key simultaneously, EEEEE appears in the display.
	Press TEST key repeatedly until P13 (frequency channel) appears in the display.

 	<p>Activate the parameter by pressing Tare button.</p> <p>Then use the TEST key to select a desired value between 01 - 28 (corresponds to channel 01 - 28).</p>
	<p>Confirm and close the parameter by pressing the ZERO key.</p> <p>The display alternately shows P13 and xx, where xx corresponds to the newly set channel number.</p>
	<p>Press the TEST key until P14 appears in the display.</p> <p>Parameter P14 is used to set the scale number.</p>
 	<p>Press the TARE key to activate the parameter.</p> <p>Then use the TEST key to select a desired value between 01 - 16 (corresponds to channel 01 - 16).</p>
	<p>Confirm and close the parameter by pressing the ZERO key.</p> <p>The display shows P14 and xx alternately, where xx corresponds to the new scale number set.</p>
	<p>Press the TEST key repeatedly until P99 appears in the display.</p> <p>Parameter P99 is used to store the changed values</p>





 	<p>Press the TARE key to activate the parameter.</p> <p>Confirm and close the parameter by pressing the ZERO key.</p> <p>Sto (Store) flashes several times on the display. This indicates that the parameter change has been successfully stored.</p>
 	<p>To exit the SETUP menu, press the Power-On and Power-Off buttons simultaneously or interrupt the power supply by disconnecting the round connectors on the battery.</p>

Table 7 -Change radio frequency and scale number

Test Software NetScale.exe Demotool




Figure 4 Net-Scale User interface

The Demotool helps to check and configurate the Net-Scale parameters. To run this tool no installation is necessary. Simply start the NetScaleG2.3.exe from any data folder. Main usecases are:

- Assign an IP-address
- Control the scale communication

① Please only change the IP address of the Net-Scale if you are familiar with the setting changes. In the event of an error, it may no longer be possible to reach the net-scale via the network.

The demo tool automatically finds all available device blocks in the network. Therefore DHCP needs to be activated or the static IP address within the the address range is set. Choose your Net-Scale via pull-down menue IP address.

To receive data from a scale, it is necessars to enter the correct scale number and frequency channel in the software. Use the data fields Scale-No. and Frequency channel.

Function	Explanation
Set date / time	Adjusts the internal clock of the block to PC system time.
Read version number	Read the version number of Net Scale firmware.
Test scale	Start display test at scale.
Zero:	Set the corresponding scale to zero
Set/delete Tare	Moves display value of scale to tare memory. When tare is set, the value is written from memory back to the display.
Send fix tare	Fix tare input field is written to the tare memory. „0“ deletes the tare memory.
Read measured value	Reads the value from scale and writes it to the response field.
Registration network	Reads the measured value and stores a data record in the verifiable memory.
Registration manual	Registration of a weight for old net scale systems with only one scale (not in use with new systems).
Clear	Deletes content from „Response from Net-Scale“ field.
Execute	Transmit the settings to Net-Scale.

Table 8 – Functions

„Service“ Tab

Via service tab the IP-address and INI-file can be changed.




Figure 5 - Service settings

Change of IP address

Overwrite IP-address and confirm with „Change“ button (only works if DHCP is disabled, see also section UDP Protocol configuration).

Scale 99 Software

The included program Scale 99 allows to view the Alibi-data from SD-card. Data is transferred via ftp to your PC and stored in installation folder of Scale 99 Software. Ensure that port 21 is available for ftp communication at your network.

The file S99_mem.exe can be saved in any folder and started directly.




Figure 6 - Scale 99 Tool

Function	Explanation
FTP Download	Window "download alibi memory" opens
Table of contents of assembly	List of the stored alibi datasets, for every month one dataset
Update contents	Download the SD content to the window "Table of content of the assembly"
Name of alibi memory	Only download the SD card content to the window "Table of content of the assembly" with exactly the data stored here. If the contents are empty all SD card data is loaded
IP address	Enter the IP address of the Net-Scale you would like to query
User name	B (stored)
Password	nsc (stored)
Delete file after download	If the check mark is set, the selected alibi file will be deleted immediately after download
Download	Download the file contents to the editor window of the Scale 99 interface, in parallel the alibi memory file is stored in the installation folder of Scale 99
Cancel	Cancels the action
Print	Prints the contents of the alibi memory
Month	Selection of month for the long term memory
Year	Selection of year for the long term memory
Long term memory	Opens the file with the respectively entered data from month and year, if these were stored in the installation folder.
Folder symbol	Opens any alibi file stored via the explorer.

Table 9 - function table

The alibi files S99_xxx.MEM stored to the SD card or downloaded from the Net-Scale, can be viewed with an editor. Manipulation of the files is not possible as they are secured by a checksum. The Scale 99 software would detect such a manipulated file as corrupted.

Byte #	ASCII	Bedeutung
1.	A-P	Scales number A=scales 01.....P16=scales 16
2.	0-9	Ten thousands alibi reference number
3.	0-9	Thousands alibi reference number
4.	0-9	Hundreds alibi reference number
5.	0-9	Ten alibi reference number
6.	0-9	Unit alibi reference number
7.	Day	0-3
8.	Day	0-9
9.	Month	0-1
10.	Month	0-9
11.	Year	2
12.	Year	0-1
13.	Year	0-9
14.	Year	0-9

Byte #	ASCII	Bedeutung
15.	Hour	0-2
16.	Hour	0-9
17.	Minute	0-5
18.	Minute	0-9
19.	Second	0-5
20.	Second	0-9
21.	Blank (20H)	free (space HEX20)
22.	Blank (20H)	free (space HEX20)
23.	Digit 5	Ten thousands of the weight
24.	Digit 4	Thousands of the weight
25.	Digit 3	Hundreds of the weight
28.	Digit 2	Tens of the weight
29.	Digit 1	Unit of the weight
30.	k	k
31.	g	g
32.	Blank (20H) or 0	
33.		free (space HEX20)
34.	Blank (20H) or 0	free (space HEX20)
35.	Digit 5	Ten thousands tare
36.	Digit 4	Thousands tare
37.	Digit 3	Hundreds tare
38.	Digit 2	Ten tare
39.	Digit 1	Unit tare
40.	k	k
41.-55.	g	g
56.-60.	IP	IP address of Net Scales

Table 10 - data format S99

Functions: Important notes

Before the Net-Scale can receive data from scales, the communication between scales and Net-Scale has to be started. The first query using the command 05xx;f8 to scales always receives the response “E4” (also see “datasets for weighing operation”).

If the scales are within the radio range, switched on, have the correct scales number and the correct channel, they are taken in to a “scales pool” and maintained there. The Netscale now automatically queries the data of the scales in a continuous rhythm.

- In this way, further scales can be taken in to the scales pool.
- Each scales taken in to the scales pool is now queried in a rhythmic sequence.

Scales have to be and will be automatically removed from the scales pool, if they are operated outside the radio link, switched off or if the checksum of the scales dataset has an error. The latter happens quite often if the radio link is disturbed by a different radio link or atmospheric influences.

- Scales lost in the scales pool can be taken in to the query routine again using the method described above.
- To improve the radio connection an antenna with higher gain can be ordered (Article no.: 77979). In many cases, this significantly improves communication between scales and Net-Scale.
- Only positive weight values can be registered. If you try to register a negative weight, the Net-Scale responds with error “E2”.
- **For use in Germany, the delivery notes or invoices have to carry a certain note: “Measured weights originate from a non-calibrated additional device. The measured weights of the calibrated scale can be viewed”. The operator of the scales carries the sole responsibility for a safe archiving of the files.**

EHP Servicehotline

Do you need our support?

No problem - just call us free of charge!



**Reach our technical experts from Monday to Thursday between 8 am & 4 pm (CET) and
Friday between 8 am & 12 am (CET)**



EHP Wägetechnik GmbH

Dieselstraße 8 • D-77815 Bühl (Baden)

Tel. +49 (0) 7223 9366-0 • Fax +49 (0) 7223 936660

E-mail: info@ehp.de • www.ehp.de